


# 16-BOTTLE BAMBOO WINE RACK

Model No. 04737

## ASSEMBLY INSTRUCTIONS



### Customer Service

Tel 1.310.533.3800

Tel 1.800.323.5565

Fax 1.310.533.3899

Monday through Friday 8:30 am - 4:30 pm (Pacific Time)



Seville Classics, Inc.

Torrance, CA 90501 USA

[www.sevilleclassics.com](http://www.sevilleclassics.com)

Please read and save these instructions

©2013 Seville Classics, Inc.



Please make sure you have all the parts before assembly

A	1 pc	B	10 pcs	C	4 pcs
Wine Rack		Long Screws		Short Screws	
		 (pre-inserted in the unit)			

**Step 1:**

Use a Phillips screwdriver to loosen the 10 **Long Screws (B)** that have already been pre-inserted in the unit. Do NOT remove the screws from the unit. Simply loosen them to carefully unfold the unit.

NOTE: Do NOT place the unit vertically when unfolding as this may result in the unit suddenly unfolding and pinching your fingers. Find a flat surface to assemble the unit. Using an uneven surface to assemble the unit may result in uneven shelves. If the unit is uneven after assembled, loosen all the screws, adjust the unit and then retighten all the screws.

**Step 2:**

First, tighten the 10 pre-inserted long screws. Next, screw-in and tighten the 4 **Short Screws (C)** into the 4 screw holes on the unit. Do NOT over tighten the screws.

**How to Fold the Wine Rack (If Needed):**

First, fully loosen and remove all 4 short screws from the unit. Next, fully loosen, but do NOT remove, the 10 remaining pre-inserted long screws. Finally, carefully fold down the unit. Please note that the unit CANNOT be folded completely flat. Forcing the unit into a folded position without first removing the 4 short screws and fully loosening the 10 pre-inserted long screws may result in irreparable damage to the unit.

**CAUTION:**

Do NOT place the unit in high temperature area or near appliances that emit large amount of heat.

Do NOT place the unit outdoor, as exposure to direct sunlight may cause the color to fade.

Do NOT place the unit on uneven surfaces. Doing so may cause the unit to tip over.

Examine the screws periodically and tighten them if they are loose.

